Module 12: Installation, Storage, and Compute with Windows Server

25. Discuss the role of Windows Firewall in Windows Server and how to configure it.

Ans:

Select Windows Defender Firewall With Advanced Security



Open Inbound Rules in the Windows Firewall with Advanced Security window.



- Click on New Rule.
- Choose **Port** and click **Next**.
- Choose **TCP** and specify port **3389** (used for Remote Desktop Protocol).
- Select Allow the connection.
- Choose the applicable profiles (Domain, Private, Public).
- Name the rule.
- Click Finish.
- 26. What is Network Address Translation (NAT) in Windows Server, and how do you configure it?

Ans:

Step:-1

- Open Server Manager (click on the Windows icon, then select Server Manager).
- Click on "Manage" in the top-right corner and select "Add Roles and Features".
- Select "Role-based or feature-based installation", then click Next.
- Choose your server from the list, then click Next.
- Under "Roles", scroll down and check "Remote Access", then click Next.


- Under "Role Services", check "Routing", then click Next and Install.
- **Restart** your server if prompted.

Step:-2

- Click on Tools in Server Manager, then select Routing and Remote Access.
- In the **Routing and Remote Access** window, right-click your server name and choose "**Configure and Enable Routing and Remote Access**".



• Choose "Network Address Translation (NAT)" and click Next.



- Select the Network Interface
- Click Next and then Finish
- Open cmd and then check given ping (IP address)
- 27. Explain the concept of Dynamic Host Configuration Protocol (DHCP) and how to configure it in Windows Server 2016.

Ans: Step 1: Install DHCP Role

- 1. Open Server Manager > Manage > Add Roles and Features.
- 2. Select Role-based installation, choose your server, click Next.
- 3. Check DHCP Server, add features if prompted, click Next, then Install.

Step 2: Authorize DHCP Server

- 1. In Server Manager, go to Tools > DHCP.
- 2. Right-click the server name > Authorize. Refresh (F5) to confirm.

Step 3: Set Up a Scope

- 1. In DHCP console, right-click server > New Scope > Next.
- 2. Name it (e.g., "LAN Scope") > Next.
- 3. Enter IP range (e.g., 192.168.1.100 192.168.1.200), subnet mask (255.255.255.0) > Next.
- 4. Skip exclusions or add if needed > Next.
- 5. Set lease time (default 8 days) > Next.
- 6. Select Yes to configure options > Next.
- 7. Add default gateway (e.g., 192.168.1.1) > Next.
- 8. Add DNS server (e.g., 192.168.1.10) > Next.
- 9. Skip WINS > Next.
- 10. Activate scope > Next > Finish.

Step 4: Test It

- 1. Connect a client device, set to "Obtain IP automatically."
- 2. Verify it gets an IP from the scope (e.g., 192.168.1.100).

28. Describe the process of configuring DNS (Domain Name System) in Windows Server.

Ans:

Step 1: Install DNS Server Role

- 1. Open Server Manager > Manage > Add Roles and Features.
- 2. Select Role-based installation, choose your server, click Next.
- 3. Check DNS Server, add features if prompted, click Next, then Install.

Step 2: Open DNS Manager

- 1. In Server Manager, go to Tools > DNS.
- 2. The DNS Manager window opens, showing your server.

Step 3: Configure a Forward Lookup Zone

- 1. Right-click your server name > New Zone > Next.
- 2. Select Primary Zone (default) > Next.
- 3. Choose Forward Lookup Zone > Next.
- 4. Enter zone name (e.g., example.com) > Next.
- 5. Accept default zone file name > Next.
- 6. Select Do not allow dynamic updates (or configure as needed) > Next > Finish.

Step 4: Add DNS Records

- 1. Expand your server > expand Forward Lookup Zones > right-click your zone (e.g., example.com).
- 2. Select New Host (A or AAAA).
- 3. Enter:
 - o Name: e.g., www (leave blank for the root domain).
 - o IP Address: e.g., 192.168.1.10.
- 4. Click Add Host > OK > Done.

Step 5: Configure DNS Server Properties (Optional)

- 1. Right-click server name > Properties.
- 2. Forwarders Tab: Add external DNS servers (e.g., 8.8.8.8) for unresolved queries > Apply.
- 3. Interfaces Tab: Ensure it listens on the correct network interface > OK.

Step 6: Test the Configuration

- 1. On a client PC, set the DNS server to your server's IP (e.g., 192.168.1.10).
- 2. Run nslookup example.com or ping www.example.com to verify resolution.

Step 7: Verify and Save

- 1. In DNS Manager, check your zone for the new records.
- 2. Restart the DNS service (right-click server > All Tasks > Restart) if needed.

29. What is Server Manager, and how do you use it to manage servers in Windows Server?

Ans:

- Open Server Manager: Click the Server Manager icon on the taskbar or search for it in the Start menu.
- Add Servers: Click Manage > Add Servers to add remote servers by name or IP.
- Install Roles and Features: Click Add roles and features to install or remove server roles (e.g., DNS, Web Server).
- **Monitor Server Health:** View server health (CPU, memory, disk) on the **Dashboard** and check for any alerts.
- Manage Services: Click Manage > Services to start, stop, or restart services on the server.
- **Remote Management:** Add remote servers and manage them just like local ones.
- **Server Settings:** Under **Local Server**, manage settings like computer name, network, and domain.

30. Discuss the role of Remote Desktop Services (RDS) in Windows Server 2016 or 2019 and how to configure it.

Ans:

How to Configure RDS in Windows Server 2016/2019

Step 1: Install RDS Role

- 1. Open Server Manager.
- 2. Click on Manage > Add Roles and Features.
- 3. In the wizard, choose Role-based or feature-based installation.
- 4. Select the Server you want to install RDS on and click Next.
- 5. On the Select Roles page, check Remote Desktop Services.
- 6. Click Next, then Install. The server will need to reboot after installation.

Step 2: Configure RDS Deployment

- 1. After the server reboots, open Server Manager again.
- 2. In Server Manager, click Remote Desktop Services in the left pane.
- 3. Click Quick Start to begin configuring RDS deployment.
- 4. Choose Standard Deployment (for a more flexible setup).
- 5. Click Next, and follow the prompts to configure:
 - o Session Host: The server where users will connect.
 - o Connection Broker: Manages user connections.
 - Web Access: Allows users to connect via a web browser.
- 6. Complete the wizard and click Deploy.

Step 3: Configure Licensing

- 1. In Server Manager, go to Remote Desktop Services > RD Licensing.
- 2. Right-click and choose Activate Server.
- 3. Follow the prompts to activate the RDS licensing server (you'll need a license key).

Step 4: Enable Remote Desktop on Server

- 1. Go to Control Panel > System and Security > System.
- 2. Click Remote settings.
- 3. In the Remote Desktop section, select Allow remote connections to this computer.
- 4. Click Apply and OK.

Step 5: Configure User Access

- 1. On the RDS server, go to Server Manager > Remote Desktop Services > Collections.
- 2. Click Tasks > Create Session Collection.
- 3. Follow the prompts to create a collection, which groups user sessions.
- 4. Add users to the collection to grant them access.

Step 6: Test Remote Desktop Connection

- 1. From a client computer, open Remote Desktop Connection.
- 2. Enter the IP address or name of the RDS server.
- 3. Log in with a user account that has remote access permissions.